



# ENERGY AUDIT TIMELINE



The timeline for an energy audit varies by PHA and the energy audit’s level. In general, the process follows five steps:

1. PHA procures an energy audit provider.
2. Pre-audit data collection.
3. Onsite assessment.
4. Final report.
5. Project execution (implementing ECMs).

The amount of time needed to carry out an energy audit increases for more complicated (Levels 2 and 3) audits, and for larger developments or PHAs. PHAs must also include time for resident notification, as the auditor will need to access a sample of occupied units.

